

## Installation Template for TouchLink™ Wired Flush Mount Rear Housing

Procedure:

### NOTICE

**BEFORE CUTTING HOLE**, check for electrical devices or studs behind area.

1. Level this template on the wall.
2. Trace around this template to locate and mark the outline for the hole that will be cut to install the flush mount rear housing.

Template Dimensions (L x W): 7.355" x 5.545"

C0136600 Rev A